

## **Trouble Shooting Guide for Contact Adhesives**

Weak, Zipper or Spotty Bonds		
Insufficient adhesive		Apply more adhesive
Insufficient Pressure		Apply more pressure
Exceeded Open time		Shorten open time; apply another coat and rebond
Low Temperature		Raise surrounding temp to 50° F
Soft or Leggy Bonds		
Insufficient drying		Extend dry time
"Blushing" or glassy look		Extend dry time, use fans to move air
Edge Lift		
Insufficient Adhesive		Make sure edges are double coated
Adhesive not dry		Extend dry time
Core Edges weak bond		Apply double coat to edges
Bubbling		
Insufficient dry time	•••••	Extend dry time
Voids or low spots in core		Fill uneven surface or use better board
Poor lamination		Avoid trapping air, laminate from center
Warping		
Unequal expansion		Examine substrates, acclimate to temp
Seams Shrinking or lifting		
Unequal expansion		Acclimate substrates prior to lamination
Insufficient adhesive		Apply more adhesive
Insufficient pressure		Apply more pressure
Adhesive Peeling from Substrate		
Surface Contamination		Clean surfaces
Poor Adhesion		Determine if right adhesive in use
Substrates contain plasticizer	r	Determine if right adhesive in use