



PVC Seal Installation Process

1. Make sure an alcohol wipe is used on all surfaces where the PVC tape will be applied to ensure the area is clean and free of dust, oil and debris.
2. The seal should always be applied starting in the **middle** of the bottom of the window or door.
3. Leave the liner on the seal when it is being applied to prevent stretching. Only remove the liner when going around a corner. Stretching the tape will cause rolling and loss of compression.
4. The seal should be placed 1/8" (.125") from outer edge of the flange of the door or window. (See Pic Below)
If there are screw holes on the flange the seal must be placed over the holes.
5. Avoid any twisting or rolling of the seal when applying around the corners or radius.
6. The joint of both ends should be overlapped by 1/2" (.500") to create a seal.
7. **All tape must be compressed before an operator can screw through it.**

Correct Seal Placement



Incorrect Seal Placement



Seal is rolled on the inside of the flange.